

FORD NEW HOLLAND

1060739 W/ BACKPLATE

9480 9482 9484 9680 9682 9684
 9880

600116 OR 1062179-01

600116 HAS 1.75" BELLY PIN & 3.75" BETWEEN SWAY BOLTS

1062179-01 HAS 1 3/8" BELLY PIN & 4" BETWEEN SWAY BOLTS

T8010 T8020 T8030 T8040 T8050 T8.410 T8.435 T8.390
 T8:330 T8: 360 T8: 320

1061739 (BENT DRAWBAR)

OR

1064220 (STRAIGHT DRAWBAR, COFIRM BACKPLATE 36" OR 42")

T9.390 T9.450 T9.505 T9.560 T9.615 T9.670 T9.700 T9.040 T9.060 T9.615
 T9.050

1062179-01

T8.320

1064220 is the same as 1063955
if saddle is needed 87533634 (42")
1064220-BP (36")
mounting plate 87448334
Bolt kit (comes with 3 bolts) Bolt KIT

DRAWBAR

TRACTOR MODEL

TRACK

WE DO **NOT** CARRY BENT DRAWBARS!!!